



LADDER BACH

Introduction:



Composite Function Keys	Standby	Plug the cables,the standby indicator in the lens is on,press that button to turn on and press for 3s to tur
	Input	You can select the corresponding audio input when you switch the left knob.
	Mute	Press dawn to show the dot matrix tube displays:MU then theres no output from the machine.

Volume	Volume knob	Switch the right knob to adjust the volume from 00db to 60db without attenuation from input signal.
Display Materials	The display material of this machine is 5*7 red co-positive dot matrix tube.	



AC INPUT	Utility input	3-prong plug, the machine can automatically recognize the voltage of different regions
ANALOG OUT	Analog Signal	1 set of XLR,1 set of RCA outputs.
ANALOG IN	Analog Signal	2 sets of XLR,1 set of RCA inputs, select the corresponding audio source on the panel.